TABLE OF CONTENTS

Page

INTRODUCTION 3

BASIC STEPS IN SETTING UP YOUR SEWING MACHINE 3

HOW TO PREPARE YOUR MACHINE FOR SEWING

Removing bobbin case and bobbin 4
Winding the bobbin 4
Threading the bobbin case 5
Replacing bobbin case in shuttle body 5
Setting needle 6
Choosing needle and thread 6
Needle and thread sizes 7

THREADING THE MACHINE 8

STRAIGHT SEWING

Setting zigzag knob for straight sewing 9
Regulating direction of feed 9
Regulating length of stitch 9
Dropping the feed 9
Regulating pressure on material 10
Preparing for sewing 10
Beginning sewing 11
Removing the work 11
Turning corners 11
Tacking 11
Basting 11
Darning 11
Doing straight stitch embroidery 12
Binding 12
Sewing Zippers and Cording 12

ZIGZAG SEWING

Zigzag control 13
Adjusting the control for zigzag sewing 13
Making zigzag stitches 13
Satin stitch 14
Embroidering automatically 15
Setting stitch pattern discs 15
Stitch pattern chart 16
Monogramming and signature writing 17
Making cut-out applique work 17

Page

Hemstitching 17
Overlock stitch 18
Narrow straight stitch hem 18
Narrow zigzag hem 18
Flat felled seam 18
Patching with a zigzag stitch 19
Mending elastic knitwear 19
Repairing slit in material 19
Making buttonholes 19
Sewing on buttons 20
Doing zigzag embroidery 20
Blindstitching automatically 21
Ruffling, gathering and shirring 21

ELONGATOR SEWING

Adjustments for elongator sewing 22
Examples of elongator sewing 23-25

MAINTENANCE

Oiling your machine 26
Oiling the shuttle race 26
Replacing sewing light bulb 26
To tighten motor belt 27
Regulating thread tensions 28

HELPFUL HINTS

A jammed shuttle 29
Machine runs heavily 29
Loose stitches 29
Wrinkled material 30
Jammed or clogged machine 30
Machine does not feed properly 30
Machine stops while sewing 30
Bobbin does not wind properly 30
Needle thread breaks 30
Bobbin thread breaks 30
Needle breaks 30
Machine skips stitches 30

PARTS AND ACCESSORIES

How to order repair parts 31
How to obtain service 31
Accessory and Parts list 32